

= recommended settings

1 2 3 4 5 6 7 8

14

8 7 6 5 4 3 2 1

19

Part No. 020-8012-01-A
E2012 7412A 7412A
Option Switch Settings

Please note the following Optiwing Switch Settings for the SAC-1 game "EURO-HAT TRICK" production release version. These settings reflect the state of the game as of November 12, 1984. The options switches are located at G1 and H1 of the SAC-1 board, at the top-far end of the board as it sits in the SAC-1 Game Cabinet facing from the front.